



Panasonic KX-TG6021M Battery Replacement

This guide will show you how to remove and replace the battery in the Panasonic KX-TG6021M.

Written By: You Zhou



INTRODUCTION

This guide will show you how to remove and replace the battery in the Panasonic KX-TG6021M.

Step 1 — Battery



- Slide the back cover down towards the bottom of the phone to remove.

Step 2



- Pull the top of the battery towards you to remove it from the phone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 07:04:27 AM.